



ROPE HOOK PARTS



TOOLS REQUIRED





A

Rope hooks are incredibly versatile. They mount on tubing between 1.9 - 3 inches. They will mount anywhere on your tower tubing and are especially useful mounted on either side of your tower tow point.


1 : Choose your desired location for the Rope Hooks. Loosely assemble the hooks to the tower. Add a small amount of blue Loctite to each bolt first.

2 : A distance between 12 - 18 inches is required for ideal use of your Rope Hooks.



⚠ WARNING ⚠

3 : If you opt to install your Rope Hooks on either side of the tow point, angle the Rope Hooks down into the boat. This will prevent your rope from accidentally catching.



x4


1/8"




B

Once your Rope Hooks are located where you want them, tighten down the 4 bolts to firmly secure their position.

1 : Rotate each rope hook to ensure they are tight yet rotate easily.



2 : If you find your hook rotation is too tight or too loose, pry out the bolt cover and carefully adjust the tightness with a 5/32" allen key. A quarter turn in either direction should be adequate.



Bolt Cover

1/8"
5/32"




How to use Rope Hooks


A

Your Rope hooks are designed to neatly store your tow rope when not in use or neatly store the excess rope when in use.

1 : Your Rope Hooks must face away from each other as illustrated before wrapping your rope




2 : To keep your rope from unraveling, snap the end of your rope into the Rope Hook end to lock it in. Loop your handle around a hook or your tow point.




B


1 : To remove your rope from the Rope Hooks, remove your handle and unsnap your rope end from the hook.



2 : Rotate both Rope Hooks so that they face each other as illustrated. This allows you to remove the whole rope at once in a neat bundle.



C



Rope hooks work well in multiple positions on tubular towers. Multiple sets of Rope Hooks can be installed on a tower depending on your rope storage needs.

