


### HARDWARE



### TOOLS REQUIRED





### MAG SWIVEL RACK



Item no. C917-170015


\*BOARD RACK BUNGEE CORD NOT ILLUSTRATED FOR IMAGE CLARITY\*

**A** Install racks to port and starboard sides of tower.




\*\*\*THIS ITEM CAN ONLY BE MOUNTED IN THE ORIENTATION ILLUSTRATED\*\*\*

**C** 3 locations to hook bungee




2 surfboards

hook bungee on either crossbar locations



1 wakeboard / 1 surfboard


Bring bungee under crossbars and hook to backplate



Note: Store wakeboard in top slot

2 wakeboards

Bring bungee under crossbars and hook to backplate



## ⚠ ATTENTION ⚠

Roswell Wake-Air strongly recommends that a routine inspection of hardware and components be done to ensure proper function and safety and to maximize product life. If bolts are found to be loose, discontinue use until Loctite is re-applied and bolts are re-tightened.